

Preferences – (oa_pref files)




Preferences – (oa_pref files)


- Preference (oa_pref) files are text files which contain preferences used by Oasys Ltd. software.
- Preferences are settings that you do not wish to change across different PRIMER sessions.
- The oa_pref files can be stored in 4 locations:
 - OA_ADMIN – top level configuration, often the same as OA_INSTALL.
 - OA_INSTALL – installation level (location of executables).
 - HOME – users personal home area.
 - Current working directory (rarely used).



Preferences – (oa_pref files)




Preferences can be changed in this panel. In this example, the background colour of the graphics window is set.



Preferences – (oa_pref files)

- oa_pref files are read in automatically from a number of locations:



Contact us

Global / UK

T: +44 121 213 3399

E: dyna.support@arup.com

India

T: +91 40 69019723 / 98

E: india.support@arup.com

China

T: +86 21 3118 8875

E: china.support@arup.com

USA

T: +1 415 940 0959

E: us.support@arup.com

Subscribe to
our newsletter:



Follow us on:



@Oasys LS-DYNA
Environment



@Oasys LS-DYNA
Environment



@Oasys



@Oasys

<https://www.oasys-software.com/dyna/>