

Graph Properties



Graph Title and Axes



Page Number : 1

Tools

RE REPORTER PR PRIMER

Read	Write	Curves	Models
Edit	Style	Properties	Workflows
Operate	Maths	Automotive	Seismic
Macros	FAST-TCF	Title/Axes	Display
Settings	Measure	Groups	Graphs
Command Fil	Units	JavaScript	Datum

All G1

None

Display Options

Reset ALL

Legend...

☒ Use Antialiased Lines ☒ Scale with DPI

Lines ☒ Default Line Width

Symbols ☐ 1 Symbol Frequency

Grid ☒ Width FG Colour

Axis ☒ Draw Top Axis ☒ Draw Right Axis

Border ☒ Width FG Colour

Fix Styles ☐

Background Image... ☐

Foreground ☐

Swap Foreground/Background

Save Preferences to file

The title of each graph and the range, scale and labels of the axes can be set in the Title/Axes menu.

The appearance of each graph can be changed in the Display menu.

Page Number : 1

Tools

RE REPORTER PR PRIMER

Read	Write	Curves	Models
Edit	Style	Properties	Workflows
Operate	Maths	Automotive	Seismic
Macros	FAST-TCF	Title/Axes	Display
Settings	Measure	Groups	Graphs
Command Fil	Units	JavaScript	Datum

All G1

None

Title / Axes

Title X Axis Y Axis Y2 Axis Legend

Label <automatic> ☐ Automatic ☐ User Defined

☒ Display Label

☒ Add Units <automatic>

Font Default

Size 14 point

Colour Foreground

Minimum <auto> ☒ Autoscale ☐ Locked

Maximum <auto> ☒ Autoscale ☐ Locked

Axis Type ☒ Linear ☐ Logarithmic

Grid Spacing ☒ Automatic ☐ User Defined

Interval 0.0000E+00

Offset 0.0000E+00

Units ☒ Add Exponent to Label

Format Automatic

Decimal Places 3

Font Default

Size automatic

Colour Foreground

Save Preferences to file

Reset All Axes Automatic Locked


Fonts Default

Sizes automatic

Colours Foreground


Solid Axes at X=Y=0 ☐

Graph Properties




The Properties menu allows max / min data to be highlighted on the graph for each curve.

The number can be positioned using left click mouse and drag.




Graph Axes and Legend



Multiple Graphs

Several graph windows can be generated on the same graphics window Via “Graphs->Create”.


The options allow the location and number of graphs to be modified.



Multiple Graphs

The curves plotted on each graph can be chosen by selecting the corresponding graph tab in the curve manager.

Note that the same curve can be present on more than one graph and there is only one curve list (the curve manager has all the available curves). This example shows the curves plotted for Graph 2.



Contact us

Global / UK

T: +44 121 213 3399

E: dyna.support@arup.com

India

T: +91 40 69019723 / 98

E: india.support@arup.com

China

T: +86 21 3118 8875

E: china.support@arup.com

USA

T: +1 415 940 0959

E: us.support@arup.com

Subscribe to
our newsletter:



Follow us on:



@Oasys LS-DYNA
Environment



@Oasys LS-DYNA
Environment



@Oasys



@Oasys

www.oasys-software.com/dyna/